

Assembly Instructions

1. Lay out the project first and position stakes as shown.
2. Drive the stakes into the soil carefully to avoid damaging them.
3. Screw the composite timbers (or sawn lumber) into the brackets using the screws included.
4. Slide the brackets with the composite timbers (or sawn lumber) attached, onto the stakes.
5. Create additional levels by inserting the stacking joints into the top of the joint below.

