




The Easy Way to Water Your Christmas Tree!

Important: Read all instructions carefully before installing your Ever-Green Watering System.

What's In The Box?







A1. Tube Clip A2. Twist-Tie B. Bow C. Water Tube D. Christmas Present Tank/with valve & Lid



"It's disguised as a present!"

Directions: Install the Ever-Green Watering System **before** adding water to your tree stand.




1. Place Ever-Green Watering System's Tank on the floor beside your tree. **Option 1-** Remove the adhesive from the Tube Clip "A1" and stick on the upper edge inside your tree stand reservoir with the tube extending down. Note: the clip should already be attached to the tube ("C"), if not, insert one end of the Tube ("C") into the Tube Clip ("A1") about 6" from the end. **If your tree stand does not accommodate the Tube Clip ("A1") in your tree stand, please use Option 2.**

Option 2- Remove the Tube Clip and place the Watering Tube ("C") into the tree stand reservoir, then secure it to the tree trunk with the Twist-Tie ("A2"). Once the Water Tube is firmly secured to the tree trunk cut off the tail of the Twist-Tie. For both Option 1 & 2 - **EXTEND THE WATERING TUBE TO THE BOTTOM OF THE TREE STAND RESERVOIR.** Then Plug the other end of the Watering Tube ("C") into the valve found on the Tank ("D") of the watering system.

2. Fill the Ever-Green Watering System Tank ("D") with 2 gallons of water. Do not pour water directly into the tree stand. After filling the Tank ("D") with water, elevate the Tank a few feet to allow the water to flow into the tree stand. The Watering Tube ("C") should be filled with water. When the tree stand is half full with water, place the Tank back on the floor. Larger tree stands may need more water added to the tank after installation. Do not fill the Tank higher than 1" below the top of your tree stand height.

3. Attach the Velvet Bow ("B") to the top of the Tank Lid ("D"). Refill the Ever-Green Watering System as needed, no higher than 1" below the top of the tree stand reservoir. The average fresh tree will need to be frequently checked and filled every day. Avoid letting the Watering System run out of water, if it does, repeat steps #1, #2 & #3 to restart the system.

What Type of Tree Stand Do You Have?



Traditional: Is your tree stand low to the ground and holds water no more than 1" off the floor? Make sure that the Ever-Green Watering System is on the floor and fill the Tank ("D") following normal directions.

Shallow: Does your tree stand have a small (less than 1 gallon) water reservoir? Do not fill the Tank ("D") with 2 gallons of water, rather start with 1 gallon and add as necessary.

Elevated: Does your tree stand hold water above 1" off the floor? The bottom of the Ever-Green Watering System should level with the bottom of the tree stand water reservoir.

Limited Warranty: Ever-Green Seasons, Inc. warrants that the Ever-Green Watering System (the "Product"), in the normal course of use, will be free from defects for a period of one (1) year following purchase (the "Warranty Period"). Buyer's sole remedy will be the repair or replacement of a defective Product during the Warranty Period, if the Product is returned at buyer's expense. The warranty does not cover any damage to the Product due to accident, abuse or misuse or if the Product has been modified in any manner.

THE FOREGOING LIMITED WARRANTY IS IN LIEU OF ALL OTHER REMEDIES OR WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE OR PURPOSE. IN NO EVENT SHALL EVER-GREEN STSYEMS, INC. BE LIABLE FOR ANY CONSEQUENTIAL, INCIDENTAL, SPECIAL, EXEMPLARY OR PUNITIVE DAMAGES, ARISING OUT OF BUYER'S PURCHASE OR USE OR THE PERFORMANCE OF THE PRODUCT, WHETHER ARISING UNDER CONTRACT, TORT OR OTHERWISE.