

**TREE FOUNTAIN
AUTOMATIC CHRISTMAS TREE WATERER
INSTRUCTIONS**

1. Connect the plastic hose to the nipple on the underside of the WATERER. Place the unit 3-4 feet away from the tree stand with the end of the plastic hose inside the stand. Make sure at least 6"-10" length of hose lays flat on the bottom of the stand around the tree trunk.
2. Remove label on a 2-liter plastic soda or water bottle. Fill with fresh water and place the bottle upside-down inside the WATERER by placing two fingers over the opening of the filled bottle and lowering it into the unit as far as possible before removing fingers. To start the flow to the stand, raise the unit about 1ft. until air bubbles start rising inside the bottle. Set WATERER down in place.
3. Depending on the size and freshness of the tree, you may need to refill the bottle once every 4 – 6 days. (You may need to refill more frequently when tree is first put up.) Raise the unit as in Step 2 at each refill.

THE WATERER FILLS THE STAND TO A CERTAIN LEVEL (APPROX. 2" FROM FLOOR) AND STOPS AUTOMATICALLY. AS THE TREE ABSORBS THE WATER, THE SYSTEM WORKS AND CREATES A "SIPHONING" ACTION THAT FILLS THE STAND TO A CONSTANT LEVEL AT ALL TIMES.

CAUTION: When using the WATERER on stands with pans less than 3" deep, the stand must be elevated so that the rim of the pan is at least 3" from the floor. On deep stands with bottoms more than 1" above floor, elevate WATERER about the same height as the bottom of the pan. (To elevate unit, place on a piece of board, books, etc.) For free flowing water, avoid sharp bends or kinks in the hose.